

## Reference – ConfigID Request Tone

The Cetis, Inc family of SIP phones has implemented an innovative way to install phones by providing the user to download the configuration file by typing in a file name via the keypad. The ConfigID prompt is both Displayed as “Enter ConfigID” as well as played as an audible set of tones “doodle doodle”. At that prompt, you would type in the numbers for the Config file that you want to download from the tftp server to populate and characterize that set.

**For example: Typing in 1234# should retrieve filename 1234.3300IP.txt.**

When the TeleMatrix SIP set boots-up and look for its configuration file, it does so by utilizing DHCP Option 66 to find the IP address of the tftp server from which to download the file. (In many cases, the tftp server used is the one residing on the IP/PBX (and is the same IP address as the IP/PBX).



**The SIP phone must have a reference to itself in its Config file so that it will not prompt the user to Enter ConfigID every time the phone loses power. This is handled in the Config File Name field at <AUTOUPDATE CONFIG MODULE>:**

**Example: <ConfigID>.3300IP.txt = 1234.3300IP.txt**

<AUTOUPDATE CONFIG MODULE>

Download Username :user

Download password :pass

Download Server IP :10.20.0.200

**Config File Name :1234.3300ip.txt (If this field is left blank, the phone will prompt with tones)**

Config File Key :

Download Protocol :1

Download Mode :0

Download Interval :1